





Ergo-Series E7W Barrel Sauna
Half Glass Window 71D" x 81H"



Note: Please read manual before construction


Rev 4/2023

Front & Back Walls




E7W Barrel Sauna 71D" x 81H"


Details list.




Tools needed




Measuring tape




Marker pen



Circular saw



Water level




Hammer




Extra hands




Ratchet strap



Silicone gun
(Only glass-wall models)




Drill



Crescent wrench





Utility knife





Rubber mallet

Wooden front wall installation

Details




I




II

DET U Fix it diagonally to make wall more rigid during the installation.







III




Proceed with main installation manual!

Half-moon wall installation




WARNING: Do not let screws touch glass!


Half-moon wall installation




E7W Barrel Sauna 71D" x 81H"




E7W Barrel Sauna 71D" x 81H"




E7W Barrel Sauna 71D" x 81H"




E7W Barrel Sauna 71D" x 81H"




E7W Barrel Sauna 71D" x 81H"




E7W Barrel Sauna 71D" x 81H"




I



Join two boards together (as shown in diagram II) that will bridge the width of the "A" gap. It is recommended that the combined boards are approximately 1/4" wider than the gap.




If needed, trim the flat edge of the board to create the desired width.




Fasten the two halves using screws

II




III

E7W Barrel Sauna 71D" x 81H"



E7W Barrel Sauna 71D" x 81H"

Remove all temporary braces




1x DET G

6x K

Upper vent

Lower vent

3x DET F




I

2x DET 10a

2x H

2x DET 10


Pre-drill holes Ø5/32" before screws.






72" and 88" Saunas with front-glass wall have 4 pc. of DET 10a.

NB! If Your sauna equipped with front-glass wall, see front-glass wall installation manual for proper benches installation.





III







E7W Barrel Sauna 71D" x 81H"



E7W Barrel Sauna 71D" x 81H"




E7W Barrel Sauna 71D" x 81H"





E7W Barrel Sauna 71D" x 81H"

See the installation manual inside the shingles package



Check also roof shingles installation manual inside package.



E7W Barrel Sauna 71D" x 81H"

